

# KitchenAid®

**3**

CUPS  
TASSES  
TAZAS

**25** oz

**750** ML

## CHEF'S CHOPPER™ SERIES

INSTRUCTIONS

## SÉRIE CHEF'S CHOPPER™

INSTRUCTIONS

## CHEF'S CHOPPER™ SERIES

INSTRUCCIONES



KFC3100

USA: 1-800-541-6390  
Canada: 1-800-807-6777



[KitchenAid.com](http://KitchenAid.com)  
[KitchenAid.ca](http://KitchenAid.ca)

FOR THE WAY IT'S MADE.™

# Proof of Purchase & Product Registration

---

Always keep a copy of the sales receipt showing the date of purchase of your Food Chopper. Proof of purchase will assure you of in-warranty service.

Before you use your Food Chopper, please fill out and mail your product registration card packed with the unit. This card will

enable us to contact you in the unlikely event of a product safety notification and assist us in complying with the provisions of the Consumer Product Safety Act. This card does not verify your warranty.

Please complete the following for your personal records:

Model Number \_\_\_\_\_


Serial Number \_\_\_\_\_

Date Purchased \_\_\_\_\_

Store Name and Location \_\_\_\_\_

# Chef's Chopper™ Series Features

ENGLISH



**Domed Lid** must be locked in position to operate the chopper, but removes easily to add ingredients. Spices and flavorings may be added through "wet/dry" compartments located on lid top, without removing the lid. Lid is dishwasher safe.

**"Reverse Spiral Action" Stainless Steel Cutting Blade** is strong and razor sharp to quickly process small amounts of meats,

fresh or cooked fruits and vegetables, and nuts and herbs. Reverse spiral design pulls foods down into blade for uniform chopping, and minimizes need to scrape sides of bowl. Blade is dishwasher-safe.

**Full 3-Cup (750 ml) Capacity Work Bowl** handles everyday processing needs. Dishwasher-safe.

# KitchenAid® Chef's Chopper™ Series Warranty

| Length of Warranty:   | KitchenAid Will Pay For:  | KitchenAid Will Not Pay For:  |
|---|---|---|
| <p><b>50 United States, the District of Columbia, Canada, and Puerto Rico:</b> One-year limited warranty from date of purchase.</p> | <p><b>50 United States, the District of Columbia and Canada:</b> Hassle-free replacement of your Food Chopper. See the following page for details on how to arrange for replacement.<br/>OR<br/><b>In Puerto Rico:</b> The replacement parts and repair labor costs to correct defects in materials and workmanship. Service must be provided by an Authorized KitchenAid Service Center. To arrange for service, follow the instructions on page 10.</p> | <p>A. Repairs when Food Chopper is used in other than normal single family home use.<br/>B. Damage resulting from accident, alteration, misuse or abuse or use with products not approved by KitchenAid.<br/>C. Replacement parts or repair labor costs for Food Chopper when operated outside the country of purchase.</p> |

**DISCLAIMER OF IMPLIED WARRANTIES; LIMITATION OF REMEDIES** IMPLIED WARRANTIES, INCLUDING TO THE EXTENT APPLICABLE WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE EXCLUDED TO THE EXTENT LEGALLY PERMISSIBLE. ANY IMPLIED WARRANTIES THAT MAY BE IMPOSED BY LAW ARE LIMITED TO ONE YEAR, OR THE SHORTEST PERIOD ALLOWED BY LAW. SOME STATES AND PROVINCES DO NOT ALLOW LIMITATIONS OR EXCLUSIONS ON HOW LONG AN IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS LASTS, SO THE ABOVE LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU.

IF THIS PRODUCT FAILS TO WORK AS WARRANTED, CUSTOMER'S SOLE AND EXCLUSIVE REMEDY SHALL BE REPAIR OR REPLACEMENT ACCORDING TO THE TERMS OF THIS LIMITED WARRANTY. KITCHENAID AND KITCHENAID CANADA DO NOT ASSUME ANY RESPONSIBILITY FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES. This warranty gives you specific legal rights and you may also have other rights which vary from state to state or province to province.

## Hassle-Free Replacement Warranty – 50 United States and District of Columbia

---

We're so confident the quality of our products meets the exacting standards of KitchenAid that, if your Food Chopper should fail within the first year of ownership, KitchenAid will arrange to deliver an identical or comparable replacement to your door free of charge and arrange to have your original Food Chopper returned to us. Your replacement unit will also be covered by our one year limited warranty. Please follow these instructions to receive this quality service.

If your Food Chopper should fail within the first year of ownership, simply call our toll-free Customer Satisfaction Center at 1-800-541-6390 Monday through Friday, 8 a.m. to 8 p.m. (Eastern Time), or Saturday, 10 a.m. to 5 p.m. Give the consultant your complete shipping address. (No P.O. Box numbers, please.)

When you receive your replacement Food Chopper, use the carton and packing materials to pack up your original Food Chopper. In the carton, include your name and address on a sheet of paper along with a copy of the proof of purchase (register receipt, credit card slip, etc.).

## Hassle-Free Replacement Warranty – Canada

---

We're so confident the quality of our products meets the exacting standards of the KitchenAid® brand that, if your Food Chopper should fail within the first year of ownership, KitchenAid Canada will replace your Food Chopper with an identical or comparable replacement. Your replacement unit will also be covered by our one year limited warranty. Please follow these instructions to receive this quality service.

If your Food Chopper should fail within the first year of ownership, take the Food Chopper or ship collect to an Authorized KitchenAid Service Centre. In the carton include your name and complete shipping address along with a copy of the proof of purchase (register receipt, credit card slip, etc.). Your replacement Food Chopper will be returned prepaid and insured. If you are unable to obtain satisfactory service in this manner call our toll-free Customer Interaction Centre at 1-800-807-6777. Or write to us at:

Customer Interaction Centre  
KitchenAid Canada  
1901 Minnesota Court  
Mississauga, ON L5N 3A7

# How to Arrange for Warranty Service in Puerto Rico

---

Your Food Chopper is covered by a one-year limited warranty from the date of purchase. KitchenAid will pay for replacement parts and labor costs to correct defects in materials and workmanship. Service must be provided by an Authorized KitchenAid Service Center.

Take the Food Chopper or ship prepaid and insured to an Authorized KitchenAid Service Center. Your repaired Food Chopper will be returned prepaid and insured. If you are unable to obtain satisfactory service in this manner, call toll-free 1-800-541-6390 to learn the location of a Service Center near you.

## How to Arrange for Service after the Warranty Expires – All Locations

---

Before calling for service, please review the Troubleshooting section on page 7.

**For service information in the 50 United States, District of Columbia, and Puerto Rico,**  
call toll-free 1-800-541-6390.

Or write to:  
Customer Satisfaction Center  
KitchenAid Portable Appliances  
P.O. Box 218  
St. Joseph, MI 49085-0218

Or contact an Authorized Service Center near you.

**For service information in Canada,**  
call toll-free 1-800-807-6777.

Or write to:  
Customer Interaction Centre  
KitchenAid Canada  
1901 Minnesota Court  
Mississauga, ON L5N 3A7

## How to Arrange for Service Outside these Locations

---

Consult your local KitchenAid dealer or the store where you purchased the Food Chopper for information on how to obtain service.

**For service information in Mexico,**  
call toll-free  
01-800-024-17-17  
(JV Distribuciones)

Or

01-800-902-31-00  
(Industrias Birtman)

## How to Order Accessories and Replacement Parts

---

**To order accessories or replacement parts for your Food Chopper in the 50 United States, District of Columbia, and Puerto Rico,**

call toll-free 1-800-541-6390 Monday through Friday, 8 a.m. to 8 p.m. (Eastern Time), or Saturday, 10 a.m. to 5 p.m.

Or write to:

Customer Satisfaction Center,  
KitchenAid Portable Appliances,  
P.O. Box 218,  
St. Joseph, MI 49085-0218

**To order accessories or replacement parts for your Food Chopper in Canada,**

call toll-free 1-800-807-6777.

Or write to:

Customer Interaction Centre  
KitchenAid Canada  
1901 Minnesota Court  
Mississauga, ON L5N 3A7

**To order accessories or replacement parts for your Food Chopper in Mexico,**

call toll-free  
01-800-024-17-17  
(JV Distribuciones)

Or

01-800-902-31-00  
(Industrias Birtman)